



BUT**NOTICE DE MONTAGE / ASSEMBLY INSTRUCTIONS****BUT International, 1 avenue Spinoza, 77 184 EMERAINVILLE**

REFERENCE NO.	4894223226783	IMITATION CHENE& NOIR/OAK&BLACK
NOM DU PRODUIT.	BONO BUREAU	
EAN:	4894223226783	IMITATION CHENE& NOIR/OAK&BLACK



Tous les papiers
se trient et se recyclent




FR

1. Repérez les différentes pièces nécessaires à l'assemblage de votre meuble.
 2. Regroupez et comptez les pièces de quincaillerie.
 3. Munissez-vous de l'outillage nécessaire à l'assemblage de votre meuble.
 4. Aménagez-vous un espace propice à l'assemblage; moquette et couverture peuvent protéger votre meuble des rayures
 5. Procédez au montage sans forcer. Il est recommandé de resserrer les vis au fil de l'utilisation.
 6. Après assemblage de ce produit, il est conseillé d'aérer régulièrement la pièce pendant quelques jours.
- CONSERVEZ VOTRE NOTICE DE MONTAGE. SI UNE PIÈCE VENAIT À MANQUER, L'INFORMATION RELATIVE À CELLE-CI FOURNIE PAR LA NOTICE DE MONTAGE RESTE LE MOYEN LE PLUS EFFICACE DE COMMUNIQUER AVEC VOTRE MAGASIN.



EN

1. Identify the parts which make up your piece of furniture.
 2. Gather the hardware parts and count them.
 3. Have the necessary assembly tools ready.
 4. Organize a space for assembly, wall carpeting or a blanket will protect the furniture against scratches.
 5. Never force the assembling while you put the parts together. You are recommended to tighten the screws after the furniture has been used for some time.
 6. After assembling this product, it is advisable to regularly ventilate the room for a few days.
- KEEP THE ASSEMBLY INSTRUCTION. THE RELEVANT INFORMATION YOU CAN FIND ON IT WILL HELP YOU GET IN TOUCH WITH YOUR STORE IF A PART WAS TO BE MISSING.



No.	Taille	Qté	Ctn no.
No.	Size	Qty	Ctn no.
No.	Tamaño	Cant	Ctn no.
1	799x176.5x15mm	x1	1/1
2	799x210x15mm	x1	1/1
3	799x460x15mm	x1	1/1
4	172x135x15mm	x2	1/1
5	1390x460x20mm	x2	1/1

No.	Taille	Qté	Ctn no.
No.	Size	Qty	Ctn no.
No.	Tamaño	Cant	Ctn no.
6	800x30x20mm	x2	1/1
7	Dia8x1007mm	x2	1/1

Quincailleries/Hardware/Herrajes/ Montageteile- Ctn no./Kto.nr.	1
---	---


A	x4	B	x4	C	x4	D	x8	E	x4	F	x1	G	x8
ø 6x35mm		ø 15x10mm		ø 5x40mm		ø 6x40mm		ø 6x30mm		ø 6x12mm		ø 7x60mm	
H	x5	I	x4	J	x1	K	x1						



TEMPS DE MONTAGE : 20 MINUTE
SET-UP TIME : 20 MINUTE



OUTILLAGE :
TOOLS:





NOMBRE DE PERSONNES : 02
NUMBER OF PERSONS : 02



POUR L'ENTRETIEN, UN CHIFFON DOUX SUFFIRA.
FOR GENERAL CARE, A PIECE OF CLOTH WILL BE ENOUGH



SAV / Spare Part s				EAN:			
(No. / Nr)x(Qté/Qty)							
Ax4		Ex4		Ix4			
Bx4		Fx1		Jx1			
Cx4		Gx8		Kx1			
Dx8		Hx5					

1




A	x4
ø 6x35mm	

2




B	x4
ø 15x10mm	

3



C	x4
	
Ø 5x40mm	


4




D	x4
	
Ø 6x40mm	


J	x1
	

5




D	x4	G	x8	J	x1
					
Ø 6x40mm		Ø 7x60mm			

6



I	x4
	

7



E	x4	F	x1	H	x5	J	x1	K	x1
									
Ø6x30mm		Ø6x12mm							

8

